# Grandstream GXW42XX Gateway

GXW4216, 4224, 4232 and 4248 Admin Guide

	1 3 5 7 9 11 13 15 LD 2 4 6 8 10 12 14 16 AC	GRANDSTREAM 0XW4216
	1 3 6 7 9 11 13 16 17 19 21 23 LD 2 4 6 8 10 12 14 16 19 29 22 24 AC	K GRANDSTREAM 0XW1224
	15 27 29 31 1 3 5 7 9 11 13 15 17 19 21 22 25 27 29 31 LK 6 28 30 32	K GRANDSTREAM GXW4232
1	3 6 7 9 11 13 15 17 19 21 23 26 27 29 31 33 35 37 39 41 43 46 47 LM 4 6 8 10 12 14 16 19 20 22 24 26 28 30 32 34 36 38 40 42 44 46 48 AC	K GRANDSTREAM CXW4245



## **Chapters**

- How to Find the IP Address
- How to Find the MAC Address
- How to Set the Configuration Server
- How to Restore Factory Default

## How to Find the IP Address

### **Quick Steps**

- 1. Pick up the connected handset and dial \*\*\* to access the main menu for device configuration.
- 2. Wait to be instructed to enter your command.
- 3. Dial 002 and the IP Address will be played to you.

## How to Find the MAC Address

### **Quick Steps**

- 1. Pick up the connected handset and dial \*\*\* to access the main menu for device configuration.
- 2. Wait to be instructed to enter your command.
- 3. Dial 010 and the MAC Address of the unit will be announced to you.

## How to Set the Configuration Server

### **Quick Steps**

- 1. Enter the IP Address into a local web browser address field.
- 2. When prompted, enter "admin" as the password.

Password ••••
Login

3. Click on the "Advanced Settings" option at the top.

Grandstream Device Configuration									
<u>STATUS</u>	BASIC	SETTINGS	ADVANCE	D SETT		ROFILE 1 PF	ROFILE 2	FXS PORTS	
MAC Address:	WAN-	- 00:00:00	:00:00:00	LAN	00:00:00:	00:00:00 ( <b>D</b>	evice MA	. <b>C</b> )	
WAN IP Address:	10.10.0.241								
Product Model:	HT-502 V1.2A								
Software Version:	Software Version: Program 1.0.7.6 Bootloader 1.0.0.15 Core 1.0.7.1 Base 1.0.7.6 CPE 1.0.1.19								
System Up Time:	09:06:40 up 7 days								
PPPoE Link Up: Disabled									
NAT:									
Port Status:	Port	Hook	Registration	DND	Forward	Busy Forwar	rd Delaye	ed Forward	
	FXS 1	On Hook	Registered	No					
	FXS 2	On Hook	Registered	No					
All Rights Reserved Grandstream Networks, Inc. 2006-2011									

4. Define the Config Server Path to your PBX. Generally this would be the IP Address, such as 10.10.0.1 used in our example. Then press "Save" at the bottom of the page.

Grandstream Device Configuration						
STATUS BASIC SETTINGS	ADVANCED SETTINGS PROFILE 1 PROFILE 2 FXS PORTS					
Admin Password: [ (purposely not displayed for security protection)						
Layer 3 QoS:	12 (Diff-Serv or Precedence value)					
Layer 2 QoS:	802.1Q/VLAN Tag       0       802.1p priority value       0       (0-7)         802.1p priority value (NATed traffic)       0       (0-7)					
STUN server is :	(URI or IP:port)					
Keep-alive Interval:	[20 (in seconds, default 20 seconds)					
Use STUN to detect network connectivity:	<ul> <li>No</li> <li>Yes, total STUN response misses 3 to restart DHCP (mininum=3)</li> </ul>					
Firmware Upgrade and Provisioning: Upgrade Via • TFTP HTTP HTTP Firmware Server Path: 19-10.0.1/grandstream/2 Config Server Path 10.10.0.1/						

## How to Restore Factory Default

#### **Quick Steps Using Reset Button**

- 1. Unplug the Ethernet cable.
- 2. Locate a needle-sized hole on the back panel of the gateway unit next to the power connection.
- 3. Insert a pin in this hole and press for more than 4 seconds.
- 4. Take out the pin and all unit settings are now restored to factory settings.



#### **Quick Setps Using IVR Command**

- 1. Pick up the connected handset and dial \*\*\* to access the main menu for device configuration.
- 2. Dial 099 and wait for the reset voice prompt.
- 3. Enter the MAC Address of the device using the following mapping.
  - 0-9:0-9.
  - A: 22
  - B: 222
  - C: 2222
  - D: 33
  - E: 333
  - F: 3333
- 4. Wait 15 seconds and the device will automatically reboot and restore factory settings.



# (920) 886-8130

http://schmoozecom.com