Grandstream Gateways & ATA's

нт-286, 502, 503, 701, 702, 704, GWX-4008 & 4004 Admin Guide





Chapters

- Find the IP Address
- Find the MAC Address
- Set the Configuration Server
- Reset to Factory Defaults

Find the IP Address

Quick Steps

- 1. Lift the handset of the phone connected to your ATA, Dial *** to initiate the IVR Menu
- 2. Wait to be instructed to enter your command.
- 3. Dial 02 and the IP address will be played to you.

Find the MAC Address

Quick Steps

- 1. Find the IP Address of the device and open a web browser to the IP address of the device.
- 2. Login with the device admin password. Default factory password is admin.

Grandstream Device Configuration				
Password				
Login				
All Rights Reserved Grandstream Networks, Inc. 2006-2011				

3. On the main page you can see the MAC address.

Grandstream Device Configuration									
<u>STATUS</u>	BASIC	SETTINGS	ADVANCE	D SETT	<u>'INGS PI</u>	ROFILE 1	PROFILE 2	FXS PORTS	
MAC Address:	WAN 00:00:00:00:00:00 LAN 00:00:00:00:00 (Device MAC)								
WAN IP Address:	10.10.0.241								
Product Model:	HT-502 V1.2A								
Software Version:	Program 1.0.7.6 Bootloader 1.0.0.15 Core 1.0.7.1 Base 1.0.7.6 CPE 1.0.1.19								
System Up Time:	09:06:40 up 7 days								
PPPoE Link Up:	Disabl	Disabled							
NAT:	NAT:								
Port Status:	Port	Hook	Registration	DND	Forward	Busy Forw	ard Delay	ed Forward	
	FXS 1	On Hook	Registered	No					
	FXS 2	On Hook	Registered	No					
All Rights Reserved Grandstream Networks, Inc. 2006-2011									

Set the Configuration Server

Quick Steps

- 1. Find the IP address of the device and open a web browser to the IP address.
- 2. Login with the device admin password. Default factory password is admin

Grandstream Device Configuration					
Password					
Login					
All Rights Reserved Grandstream Networks, Inc. 2006-2011					

3. Click on the "Advanced Settings" option at the top.

Grandstream Device Configuration									
<u>STATUS</u>	BASIC	SETTINGS	ADVANCE	D SETT	<u>INGS PI</u>	ROFILE 1	PROFILE 2	FXS PORTS	3
MAC Address:	WAN 00:00:00:00:00:00 LAN 00:00:00:00 (Device MAC)								
WAN IP Address:	10.10.0.241								
Product Model:	HT-50	HT-502 V1.2A							
Software Version:	Program 1.0.7.6 Bootloader 1.0.0.15 Core 1.0.7.1 Base 1.0.7.6 CPE 1.0.1.19								
System Up Time:	09:06:40 up 7 days								
PPPoE Link Up:	Disabl	Disabled							
NAT:	NAT:								
Port Status:	Port	Hook	Registration	DND	Forward	Busy Forw	ard Delay	ed Forward	
	FXS 1	On Hook	Registered	No					
	FXS 2	On Hook	Registered	No					
All Rights Reserved Grandstream Networks, Inc. 2006-2011									

4. Define the Config server path to your PBX. Generally this would be the IP address such as 10.10.0.1, used in our example. Press the "Save" button at the bottom.

Grandstream Device Configuration						
STATUS BASIC SETTINGS	ADVANCED SETTINGS PROFILE 1 PROFILE 2 FXS PORTS					
Admin Password:	(purposely not displayed for security protection)					
Layer 3 QoS: 12	2 (Diff-Serv or Precedence value)					
Layer 2 QoS: 80 80	2.1Q/VLAN Tag 0 802.1p priority value 0 (0-7) 2.1p priority value (NATed traffic) 0 (0-7)					
STUN server is :	URI or IP:port)					
Keep-alive Interval: 20	(in seconds, default 20 seconds)					
Vo Use STUN to detect network connectivity: O Yes, total STUN response misses To restart DHCP (mininum=3)						
Firmware Upgrade and Provisioning: Upgrade Via 💿 TFTP 🕥 HTTP 🚫 HTTPS						
Firmware Server Path: 10.10.0.1/grandstream/2						
	Config Server Path: 10.10.0.1/					

Reset to Factory Defaults

Quick Steps

- 1. Lift the handset of the phone connected to your ATA, Dial *** to initiate the IVR menu.
- 2. Wait to be instructed to enter your command.
- 3. Dial 73738 and press "1" to confirm, when prompted.



(920) 886-8130

http://schmoozecom.com