

# Do Not Disturb Guide

Aastra 6731

# Schmooze<sup>®</sup>

*Schmooze Com Inc.*



DND is a feature that, when enabled, forces all internal or external callers straight to your voicemail box. It is typically used when the user is in a meeting and does not want their phone to ring.



To enable DND, press the DND button on the phone. When DND has been enabled the light next to the DND button will be lit up red and the screen on the phone will show "DND activated."



To disable DND, press the DND button on the phone. When DND has been disabled the light next to the button will be turned off and there will be no text on the phone screen.

