






Chapters

- How to Find the IP Address
- How to Find the MAC Address
- ▶ How to Set the Configuration Server
- ▶ How to Restore Factory Default

How to Find the IP Address

Quick Steps

- With the device connected via Ethernet cable, click on the link below to download and install the free GSurf_Pro software from the Grandstream website.
 - http://www.grandstream.com/products/tools/surveillance/GS_Search.zip
- 2. Click the "Search" button and the detected devices will appear in the Output field.



3. The IP Address for this device will display in the IP column.



How to Find the MAC Address


Quick Steps

1. Once the device is detected using the GSurf_Pro software, double click the device. Your browser will automatically open and link to the device IP and the web configuration page.

Index	Model	Version	Device Name	IP	HTTP Port	RTSP Port	MAC
1	IPCAMERA 3672HD	1.0.4.43	GXV3672HD	10.10.0.1	80	554	00:0B:82:41:68:4E


2. From the home page, click on "Configuration" at the bottom left. The default username is "admin" and the default password is "admin".








3. Under Basic Settings on the left, click "Status".



4. The MAC Address will display under Network Status.






How to Set the Configuration Server


Quick Steps

1. Once the device is detected using the GSurf_Pro software, double click the device. Your browser will automatically open and link to the device IP and the web configuration page.

Index	Model	Version	Device Name	IP	HTTP Port	RTSP Port	MAC	
1	IPCAMERA 3672HD	1.0.4.43	GXV3672HD	10.10.0.1	80	554	00:0B:82:41:68:4E	


2. From the home page, click on "Configuration" at the bottom left. The default username is "admin" and the default password is "admin".








3. Under Advanced Settings on the left, click "Maintenance".



4. Then under Firmware Upgrade and Provisioning, define the Config server path to your PBX. Generally this would be the IP address such as 10.10.0.1, used in our example. Press the "Save" button at the bottom.





How to Restore Factory Default


Quick Steps

1. Once the device is detected using the GSurf_Pro software, double click the device. Your browser will automatically open and link to the device IP and the web configuration page.

Index	Model	Version	Device Name	IP	HTTP Port	RTSP Port	MAC
1	IPCAMERA 3672HD	1.0.4.43	GXV3672HD	10.10.0.1	80	554	00:0B:82:41:68:4E


2. From the home page, click on "Configuration" at the bottom left. The default username is "admin" and the default password is "admin".








3. Under Advanced Settings on the left, click "Maintenance".



4. Then under Restore the device, press the "Restore" button.



5. The device is now reset to factory default.



(920) 886-8130

http://schmoozecom.com