

Yealink T18P

Admin Guide



Schmooze[®]

Schmooze Com Inc.



How To Find The IP Address

Quick Steps

1. Pick up the handset and dial out “**90#” to obtain the IP address of the phone.
2. The IP address will be played back to you.

How To Find The MAC Address

Quick Steps

1. Find the IP Address of the Phone and open a web browser to the IP address of the phone.
2. Login with the phone admin password. Default password is “admin.”

A username and password are being requested by http://10.4.0.179. The site says “Enterprise IP phone SIP-T18P”

User Name:

Password:

3. On the main page you can now see the MAC and IP Address of the phone.

Version	
Firmware Version	18.0.0.80
Hardware Version	9.0.0.6
Network ?	
WAN Port Type	DHCP
WAN IP Address	10.10.0.175
Subnet Mask	255.255.255.0
MAC Address	00-15-65-23-23-AB
Link Status	Connected
Account	
User Name	4406
SIP Server	10.10.0.1:5060
Register Status	Registered



How To Set The Configuration Server

Quick Steps

1. Find the IP Address of the Phone and open a web browser to the IP address of the phone.
2. Login with the phone admin password. Default password is “admin.”

A username and password are being requested by http://10.4.0.179. The site says “Enterprise IP phone SIP-T18P”

User Name:

Password:

3. Click on the “Upgrade” tab at the top then “Advanced” option tab under Upgrade.

Yealink
Enterprise UCP

Status Account Network Phone Call Log Upgrade Security

Basic | Advanced

Firmware Version

Firmware Version 18.0.0.80

Hardware Version 9.0.0.6

Reset to Factory Setting ?

Reboot System Now

Select and Upgrade Firmware

NOTE

Reset to Factory Setting
Reset all the settings of the phone to default configurations.

Select and Upgrade Firmware
Select and upgrade the file from the hard disk or network.

4. Define the URL to your PBX. Generally this would be IPADDRESS such as 10.10.0.1/ in our example and press the “Confirm” button at the bottom.

Yealink
Enterprise UCP

Status Account Network Phone Call Log Upgrade Security

Basic | Advanced

Custom Option(128 ~ 254) ?

Custom Option Type String

URL http://10.10.0.1

Account

Password

Common AES Key

MAC-Oriented AES Key

PNP config Disabled

Check New Config Disabled

Click this button to auto provision immediately

Export / Import Config

System Log Disabled

Export System Log Local

NOTE

Custom Option
Specify the DHCP Option that you want to use for provisioning. Refer to Auto Provision Manual for details about provisioning.

AES Key
It is provided by ISP.

Click this button to auto provision immediately
Click this button to auto provision immediately.

Export/Import Config
Export the configuration files to backup the settings, and could import all the settings after reset.

System Log
There are two methods to export the system log, Local or Server.



How To Factory Default

Quick Steps

1. Find the IP Address of the Phone and open a web browser to the IP address of the phone.
2. Login with the phone admin password. Default password is “admin.”

A username and password are being requested by http://10.4.0.179. The site says “Enterprise IP phone SIP-T18P”

User Name:

Password:

3. Click on the Upgrade tab at the top.

The screenshot shows the Yealink web interface with the 'Upgrade' tab selected. The 'Reset to Factory Setting' button is highlighted. The interface also shows the 'Firmware Version' section with 'Firmware Version' 18.0.0.80 and 'Hardware Version' 9.0.0.6. A 'NOTE' section on the right provides instructions for 'Reset to Factory Setting' and 'Select and Upgrade Firmware'.

4. Click the Reset button next to the Reset to Factory Settings option.

The close-up shows the 'Reset to Factory Setting' label and the 'Reset' button with a help icon.



Schmooze[®]
Schmooze Com Inc.

(920) 886-8130

<http://schmoozecom.com>